SPECIFICATION SHEETFall protection



Galvanized Cable Anchor - Sling - Coated with PVC

CEK014

4' (1.2m)

CEK016

6' (1.8m)

This **Galvanized Steel Cable Anchor Sling** is a reliable and versatile solution for creating secure anchor points in construction and industrial environments. Made from 1/4" / 0.6cm galvanized steel wire rope, it offers excellent strength and corrosion resistance. The cable is coated with **durable PVC**, which helps prevent abrasion and environmental damage, extending the life of the sling in harsh conditions.


To create a secure anchor point, wrap the cable around a steel beam or other solid structure. Then attach a **CSA-compliant carabiner** to both eye terminations. This setup provides a secure anchorage rated up to **310 lbs** / **141kg**.

Certification

Meets and Exceeds

- ⇒ ANSI Z359.18-2017
- ⇒ ANSI A10.32-2012
- ⇒ OSHA 1910, OSHA 1926 Subpart M

Suitable for temporary or permanent anchorage setups



Galvanized steel eyerings to prevent wear and deformation of the cable loop

Material	
Cable type	Galvanized steel
Coating	Heavy-duty PVC
Eye-Rings	Galvanized steel

Capacity:


59-141kg (130-310lbs) (weight range including equipment)

Technical Data

 Minimum Breaking Strength: 5,000lbs, 22kN

Installation and Use

- Wrap the Sling: Loop the cable around a solid, secure structure such as a steel beam, pipe, or other approved anchorage point.
- Connect to the Eye: Once wrapped, connect
 a CSA-compliant carabiner or other approved connector directly to both thimbled Flemish eye terminations.
- Secure the System: Ensure the carabiner is properly locked and that the cable is snugly wrapped with no slack or movement around the anchor point.



Inspect Before Use: Always inspect the cable, coating, and terminations for signs of wear, corrosion, or damage before each use.

SPECIFICATION SHEETFall protection



Associate Products

Covers the ABC of fall protection: Anchor points, Body support (harnesses), Connecting devices (lanyards) - ensuring complete safety at height.









Maintenance and Inspection

Maintenance

- Clean after each use to maintain safety and durability.
- Remove any dust, corrosive material or contaminants.
- If the fall protection system cannot be cleaned with clean water, use mild soap and water, then rinse and wipe dry.
- NEVER clean the fall protection system with corrosive materials.

Inspection

- Before EVERY use, inspect the fall protection system for defects.
- IMMEDIATELY remove the fall protection system from service if any defects or damage are found, or if it is exposed to fall arrest forces.
- At least every 12 months, a competent person other than the user shall inspect the harness.

Important

- Users of this equipment must read and follow all manufacturer instructions, labels, and warnings for each component of the complete system before use.
 - If you do not understand any instructions, labels, or warnings related to the use or maintenance of this component, seek clarification before proceeding.
- This equipment is intended for use by trained personnel only. All users must be familiar with and adhere to applicable CSA, OSHA, and ANSI regulations.
- This product is part of a complete fall arrest system and must be used only with compatible equipment and connectors.
 - Failure to use the proper connector may result in serious injury or death.
- Any system or component that has been subjected to a fall must be immediately removed from service and destroyed.
- A comprehensive fall protection plan must include provisions for the prompt rescue of a fallen worker.



CEK01 See Instructions